




This document is meant to be used as a guide in determining suitable size options available & should not replace an actual garment fitting. Upon receipt of the garment, we recommend that it be tried on by the intended wearer to ensure proper fit prior to making any alterations.

We recommend the following in order to determine the most suitable size option:

Keep the ballistic panels inside the panel carrier when measuring.

Measure the full amount of both the ballistic panels and the excess fabric bulk created by the panel carrier.



HOW TO MEASURE										
1	Front Panel Width	With cloth tape measure, measure the ballistic carrier at the widest point of the body of the front panel. This point should fall between the bottom of the armhole & the waistline of the carrier.								
2	Front Panel Height	With cloth tape measure, measure the front height of the ballistic carrier from the center front neckline to the waistline.								
3	Back Panel Width	With cloth tape measure, measure the ballistic carrier at the widest point of the body of the back panel. This point should fall between the bottom of the armhole & the waistline of the carrier.								
4	Back Panel Height	With cloth tape measure, measure the back height of the ballistic carrier from the center back neckline to the waistline.								

	FIT GUIDE BASED ON BALLISTIC CARRIER MEASUREMENTS													
		Height	XS	S	М	L	XL	2XL	3XL	4XL	5XL	6XL		
1	Front Panel Width	Short		19	21	23								
		Regular	19	21	23	25	27	29	31	33				
		Long		22	24	26	28	30	32	34	36			
		X-Long				27	29	31	33	35	37	39		
2	Front Panel Height	Short		11 1/8	12 1/8	12 5/8								
		Regular	11 5/8	12 5/8	13 5/8	14 1/8	15 1/8	15 %	15 1/8	16 1/8				
		Long		14 1/8	15 ⅓	15 %	16 5/8	17 1/8	17 ¾	17 %	17 1/8			
		X-Long				17 1/8	18 1/8	18 5/8	18 1/8	19 1/8	19 %	19 5/8		
3	Back Panel Width	Short		17 ¾	19 ¾	21 3/4								
		Regular	17 ¾	19 ¾	21 ¾	23 ¾	25 ¾	27 ¾	29 ¾	31 ¾				
		Long		20 3/4	22 ³⁄4	24 ¾	26 ¾	28 ¾	30 ¾	32 ¾	34 ¾			
		X-Long				25 ¾	27 ³ / ₄	29 ¾	31 ¾	33 ¾	35 3/4	37 ¾		
4	Back Panel Height	Short		15 ¼	16 ¼	16 ¾								
		Regular	15 ¾	16 ¾	17 ¾	18 ¼	19 ¼	19 ¾	20	20 ¼				
		Long		18 ¼	19 ¼	19 ¾	20 3/4	21 ¼	21 ½	21 ¾	22			
		X-Long				21 ¼	22 ¼	22 3/4	23	23 ¼	23 ½	23 3/4		